

IMRELAX 260W ZOOM Waterproof RGBW LED Par Light IM-SL260



**Thank you for choosing IMRELAX Pro Stage
Lighting, we sincerely for every products.**

1. Menu



A B C D

- A. Function
- B. Up
- C. Down
- D. Enter

Operating instructions: Press the function key A to cycle out different functions, and press the B or C key to modify the parameter value. Press D to confirm.

2. Operation instructions for four-digit digital key board

Number	Menu	Function	Detail
1	d001	DMX512 Address Setting 001	Press the up and down keys to adjust the address code, press the Enter key to save.
2	r255	Red Dimming 0-255	Press the up and down keys to adjust the brightness of Red Color, and press the Enter key to save.
3	G255	Green Dimming 0-255	Press the up and down keys to adjust the brightness of Green Color, and press the Enter key to save.
4	b255	Blue Dimming 0-255	Press the up and down keys to adjust the brightness of Blue Color, and press the Enter key to save.
5	H255	White Dimming 0-255	Press the up and down keys to adjust the brightness of White Color, and press the Enter key to save.
6	F255	ZOOM adjustment 0-255	Press the up and down keys to adjust the ZOOM range, and press the Enter key to save.
7	Pr01	Build in Program 01	Press the up and down keys to choose the build in Program, and press the Enter key to save.

8	SP01	Build in Program Speed 16	Press the up and down keys to choose the speed of build in Program, and press the Enter key to save.
9	AUTO/AIDI	Auto run /Sound control	Press the up and down keys for selection, and press the Enter key to save.
10	DP-0/1	DP-1:Black screen; DP-0: Keep screen light on	Set whether to black screen, and press the Enter key to save.
11	DISP	Display selection inverted	Press the up and down keys to select the forward display or reverse display, and press the Enter key to save.
12	T25	Display current working temperature	The working temperature of the LED Chips.

3. DMX Channels List

Channels	Function	Details
Channel 1	All Dimming	RGBW dimming, linear dimming, from dark to bright
Channel 2	Strobe	Strobe from slow to fast
Channel 3	Red	Red color linear dimming, from dark to bright
Channel 4	Green	Green color linear dimming, from dark to bright
Channel 5	Blue	Blue color linear dimming, from dark to bright
Channel 6	White	White color linear dimming, from dark to bright
Channel 7	Color Mixing	Color Mixing selection
Channel 8	Build in Program	(0-20) No function; when it is greater than 20, the built-in programs are equally distributed.
Channel 9	Build in Program Speed	The speed is from fast to slow, 0 is the fastest speed.
Channel 10	ZOOM	ZOOM range adjustment
Channel 11	Reset	Light Reset

In the address code status, if there is no console connection after multiple machines are connected, the master-slave connection function can be realized, and one of the devices can be operated, and the other devices in the address d001 state will run the program synchronously with the host. After the console is turned on, if the console signal is received, the D.001 of the address code will become A.001, and the device in the address state can be controlled by the console.

More information welcome to visit: www.imrelax.com

Thank you very much!